

Installation Guide Wallpapers

Recommended tools:

- Paste for non-woven wallpapers

- Roller or brush
- Seam roller
- Wallpaper brush
- Knife
- Clean sponge or cloth
- Wallpaper trim guide
- Spirit level, ruler and pencil

Preparation

Surfaces must be clean, smooth, dry and structurally intact before installing any wall covering. Remove any old paint or wallpaper that is coming off. Clean the surface and apply filler where necessary. If the surface is porous, it should be primed before hanging the wall mural. It is also advisable to prime the surface if it has bright colours that could show through the wall mural.

Hanging Instructions – we recommend applying the paste directly to the wall

1. The panels of the wallpaper are numbered at the top in the order they should be hung. Hang from left to right.
2. Mix the wallpaper paste.
3. We recommend using markings as a guide to hang the first panel. From the far left edge of your wall, measure the width of your wallpaper and draw a straight line using a spirit level, a measuring tool and a pencil. Make sure the markings are faint so they don't show through the wall mural.
4. Apply the paste to the wall (approximately one panel width in advance).
Please note: It is important to cover the whole area with paste to avoid blisters in the wallpaper at unpasted spots.
5. Hang each sheet of the wallpaper in order. The panels should be hung edge to edge.
 - The panels should not overlap.
 - Position the pieces, ensuring that they are in line with the previous ones.
 - Use the wallpaper brush to work the panel from the centre out to expel any air bubbles. Use smoothing tools gently in order not to damage the image surface.
 - Take care to press the panels together firmly at the seams using a seam roller. Use smoothing tools gently in order not to damage the image surface.
 - To avoid damaging textured wallpapers, put a cloth under the seam roller before smoothing the seams.
 - Avoid harsh folds as this may cause cracks in the print.
6. If there are any spots of paste on the front of the wallpaper, use a damp cloth to remove them immediately.
7. Once all panels are placed, trim of any excess paper using a sharp knife and a wallpaper trim guide.

Note:

- Our wallpapers are developed to be hung dry. Use a roller or a brush to apply the paste directly to the wall. If you wish to refurbish, the dry wallpaper can be peeled off and removed easily.
- Applying adhesive to the back of the wallpaper is also possible. Please note: Non-woven wallpaper does not require booking times. After pasting, the wallpaper can be hung directly to the wall.
- Avoid draught and intense heating as this may cause open seams.
- These hanging instructions can only be seen as general guidelines because we have no influence on your working conditions or the surface where the wall mural shall be applied to. If in doubt, perform some pre-tests to verify the compatibility of the wallpaper and paste used. We will not accept any complaints deduced from this hanging instructions.